


Controlling Live TV

1. You can control live TV
 - a. Last 60 minutes are recorded
 - b. Rewind
 - c. Stop
 - d. Pause
2. DVR Controls



- a. Skip Back – Goes back 10 seconds at a time
- b. Rewind – Pressing multiple times increases speed
- c. Pause to walk away, Play to continue
- d. Skip Ahead – 30 seconds at a time
- e. Fast Forward – Pressing multiple times increases speed
- f. Slow Motion – Press “pause” and “fast forward button”
- g. Live Button – to restore to live tv