

Recording Programs

1. DVR Recording Features
 - a. Record programs to watch later
 - b. Record a program as you're watching it
 - c. Record a program while watching another
 - d. Record a program from the program guide
 - e. Schedule a series recording
2. Now Playing Feature




- a. Shows that you are currently watching
 - b. Shows what is being recorded
 - c. Shows what was just previously recorded
3. Record What You're Currently Watching



- a. If you decide to record a show that you are already watching, click "record" button
 - b. Choose if it is a "One-Time" recording, "Series", Set a "Reminder"

- c. Once your recording begins, a red circle will briefly display on the screen



- d. When recording a show that you are not already watching, hit “record”, go down to AutoTune, select “yes” and it’ll move you automatically to that channel when recording begins

- i. Once recording begins a TV with a red circle will briefly appear on the screen

4. Recording a Series




- When recording a series, click “record” button, arrow over to “series” and set the options to your liking
- Keep at most – how many episodes you want to keep
- Show Type- New episodes only or all episodes
- Start Recording/ Stop Record: On-time or early
- Folder – place the recording in a specific storage folder
- Auto-Tune – Do you want the TV to switch to that channel when recording

g. Arrow down to create the recording, hit "Ok"




h. A red circle with an "S" will show in the Program Guide on that show
5. Schedule a recording from the guide




a. As you browse the guide, to record, just hit the "record" button on your remote
b. The same record menu will pop-up

6. Stop Recording



- a. To Stop recording before it has ended, hit the “stop” button on your remote



- b. Or hit the “record” button and it’ll pull up a menu
 - i. Continue Recording
 - ii. Stop Recording and Keep
 - iii. Stop Recording, Keep and Protect
 - iv. Stop Recording and Delete

7. Search and Record



- a. Press the “search” key on the remote
- b. Highlight “New Search” and select “ok” on the remote



- c. This will bring up the search window, type in the title you are looking for using the arrows, hit “ok” to select the letter” and when completed hit the “Yellow – Search” button on your remote


- d. It'll bring up a list of programs that fit the search word, use the "browse" keys to look at the list. When you find the one you want, "hit" record and it'll bring up the recording screen
- e. You can also access the "search" menu through the main menu.
 - i. Hit "menu" on the remote. Go to Settings and select "search"

8. Reminders

- a. In the Program Guide, if you find a show you don't want to miss. Hit "record" on your remote. It'll pull up the record menu.



- b. Scroll over to "Reminder"
- c. Use the menu to create settings for the reminder
 - i. Reminder Type
 - ii. Show Reminder – When you want it to remind you
 - iii. Auto-Tune – Turn automatically on to that show
 - iv. Hit "ok" to set reminder



- v. To remove the Reminder, go to the program guide, select the show with the reminder, hit “record” to automatically take off the reminder.



- d. When the reminder shows up on your screen
 - i. Press “Ok” to tune to the program
 - ii. Press “exit” to dismiss the reminder
 - iii. Once you take any action on the screen the reminder is dismissed.